

AXIS Barcode Reader

QR Code reader for seamless access

AXIS Barcode Reader is an edge-based analytics application that works with Axis intercoms, cameras, and door controllers to offer reliable QR Code[®] entry for visitors. The reader is an essential part of a mobile credential access control solution, allowing you to provide temporary access without the cost, complications, or waste of purchasing, managing, and disposing of physical cards. It's installable on a range of Axis cameras and intercoms and perfectly complements AXIS Camera Station Secure Entry, yet it is also compatible with third-party systems, ensuring seamless integration with your preferred solution.

- > **Reliable, cost-effective QR Code reader**
- > **IP solution—no physical wiring**
- > **Scalable and edge-based**
- > **Single- and multi-door support**
- > **Flexible and future-proof**

QR Code[®] is a registered trademark of Denso Wave Incorporated in Japan and other countries.



AXIS Barcode Reader

Application

Compute platform	Edge
Licenses	Required
Supported devices	For a complete list of recommended and supported products, go to axis.com
Settings	Cooldown Text overlay Sends QR Code using OSDP and Wiegand interface protocol Supports dynamic QR Code
Security	Server certificate validation
Doors	Supports up to five doors
Configuration	Includes web configuration

Scenarios

Typical applications	Identifies and reads QR Code as a credential in use with access control systems
----------------------	---

System integration

Supported platforms	AXIS Camera Station Secure Entry OSDP and Wiegand integration with third-party physical access control system via A8207-VE MK II
Application Programming Interface	Open API for software integration, including VAPIX® and AXIS Camera Application Platform; specifications at axis.com

General

Languages	English
Access device settings	QR Code up to 200 bytes

Environmental responsibility:

axis.com/environmental-responsibility